

Boat Canopy Dismantling Guide

To ensure a safe and proper dismantling of your new Amtrim canopy, please follow these step-by-step instructions:



1. Start by removing the side panels, leaving the two highest, most central turn buttons for last. This will prevent the panel from swinging down into the water. As you fold the side panels, take care not to damage the windows.



2. Free the support legs so that they are ready to hold the framework when it's dropped.



3. Unzip the centre zip of the canopy that runs through the top panel.



4. Carefully lower the front half of the canopy, allowing it to rest on the roof of your boat.



5. While supporting the framework, let the rear half of the canopy drop back and align the support leg with the brackets on the stern rail. There is a pin that will secure the support leg to the bracket. Start with one side and then secure the other side.



6. At the rear, unclip the bottom of the canopy and neatly roll the fabric around the framework. You can secure it using a bungee cord or, if available, the optional Amtrim Rear Boot Storage Cover.



7. To avoid damaging the front windows, lift the front framework and push out the window as it drops back down to rest on the roof of your boat. The support legs should now be holding up the framework.



8. Now, you can push the remaining fabric into the space beneath the front window. Alternatively, if you have the optional Amtrim Front Boot Storage Cover, you can undo the four tensioning straps and the two hatch straps that fix this panel to the roof and roll the fabric around the framework.

You have now successfully completed the dismantling process. Your boat is ready for cruising!